

INSTALLATION INSTRUCTIONS
BILLET ALUMINUM DRIVER BOARDS
Fits 1980 & Newer FLT's, FLHT's, FLTR's and 1986 & Newer Heritage Softails
Part #HD024

1. Remove the driver board pivot bolts and lock nuts.
2. Install the new driver board in the same locations as the stock boards were removed from. Install the bolts and lock nuts. The driver board bolts should be tightened only enough to seat the nut and bolt head. The driver boards should pivot up approximately 20 degrees freely. Check that the lock nuts are secure.